

SUUNTO X6^{HR}

POCKET GUIDE

[START]

- Chrono mode: start, save lap
- Hiking mode: save bookmark
- >2 sec. = Activate the backlight

[ARROW]

- Scroll the menus and memory up and down
- Change the values of settings



[STOP/CI]

- Return to the previous menu or to the previous selection without accepting the selection
- Chrono mode: stop
- Other modes: change the lowest field
- >2 sec. = Return to the main display without accepting the last selection

[SUUNTO]

- Navigate to a lower menu level
- Accept the selections
- >2 sec. = Return to the main display and accept the selection




SUUNTO
www.suunto.com

