

## SUUNTO CUSTOMER SUPPORT

- [www.suunto.com/support](http://www.suunto.com/support)  
[www.suunto.com/mysuunto](http://www.suunto.com/mysuunto)
- |             |                   |
|-------------|-------------------|
| AUSTRALIA   | +61 1800 240 498  |
| AUSTRIA     | +43 720 883 104   |
| CANADA      | +1 800 267 7506   |
| CHINA       | +86 010 84054725  |
| FINLAND     | +358 9 4245 0127  |
| FRANCE      | +33 4 81 68 09 26 |
| GERMANY     | +49 89 3803 8778  |
| ITALY       | +39 02 9475 1965  |
| JAPAN       | +81 3 4520 9417   |
| NETHERLANDS | +31 1 0713 7269   |
| NEW ZEALAND | +64 9887 5223     |
| RUSSIA      | +7 499 918 7148   |
| SPAIN       | +34 91 11 43 175  |
| SWEDEN      | +46 8 5250 0730   |
| SWITZERLAND | +41 44 580 9988   |
| UK          | +44 20 3608 0534  |
| USA         | +1 855 258 0900   |

**SUUNTO**

© Suunto Oy 10/2015. All rights reserved.  
 Suunto is a registered trademark of Suunto Oy.



en



## SUUNTO VYPER NOVO QUICK GUIDE

**⚠ WARNING:** Read complete user guide before diving.  
[www.suunto.com/support](http://www.suunto.com/support)

**GET MORE**

**MY SUUNTO**

[www.suunto.com/mysuunto](http://www.suunto.com/mysuunto)



## ACTIVATE

1. Press [MODE] to wake up dive computer.
2. Wait for software to initialize.
3. When time and date appear, continue with adjusting settings.




## PLAN

1. Press [MODE] until you see PLAN NODEC.
2. Press [DOWN] or [UP] to scroll dive depths to check no decompress times.
3. Between consecutive dives, press [SELECT] to adjust surface time.
4. Press [MODE] to exit.



## HISTORY

1. Press [MODE] until you see MEM.
2. Switch between History and Logbook with [DOWN] or [UP].
3. Press [MODE] to exit.




## GENERAL SETTINGS

1. Keep [DOWN] pressed.
2. Scroll with [DOWN] or [UP] and enter with [SELECT].
3. Change with [DOWN] or [UP] and confirm with [SELECT].




## DIVE




## CHANGE MODES AND VIEWS

Press [MODE] to change main mode: time, dive, plan and memory.



Change bottom row views in any mode with [DOWN] and [UP].



## CHANGE DIVE MODE

The default dive mode is Air. If you want to use Nitrox, for example, change the mode under General Settings.

1. Enter **General Settings**.
2. Press [SELECT] to enter to **Dive Modes**.
3. Change to **Nitrox** with [UP].
4. Confirm with [SELECT].
5. Press [MODE] to exit.

## COMPASS


1. While in time or dive mode, keep [SELECT] pressed.
2. Turn and rotate wrist to calibrate compass if needed.
3. Press [MODE] to exit compass.



## SUUNTO WIRELESS TRANSMITTER (OPTIONAL)

### PAIR


1. Press [Mode] to change to dive mode.
2. Keep [Down] pressed to enter settings.
3. Scroll to **Tank Press Pairing** with [Up] and press [Select].




4. Press [Up] to turn pairing on and confirm with [Select].




5. Press [Mode] to exit settings.
6. Hold dive computer next to transmitter until code appears.




7. Transmission icon indicates active connection.



### LOW BATTERY




### HIGH PRESSURE



### NO CONNECTION



1. Breathe in gas and hold dive computer next to transmitter.



2. If still no connection, clear code under **Tank Press Pairing** setting and re-pair transmitter.