Daily Alarm Indicator

Dive Alarm Indicator

Safety Stop Indicator

Tank Pressure Bar

Wireless Transmission

Maximum Depth

Indicator

Dual Time

O, (Nitrox)

Tank Pressure

Date

Time

No-Fly Icon

Current Depth

8888 ACCOUNTS ASSESSED IN THE PROPERTY OF THE

Low Battery Warning

SUUNTO D6i QUICK GUIDE

▲ WARNING: Read complete user quide before diving. www.suunto.com/support

ACTIVATE

Active Water Contact

Diver Attention Symbol

No-Decompression Time

Safety Stop/Deepstop Time

Mode Indicator

Ceiling Depth

No-Fly Time

Apnea Timer

Compass Stopwatch (Timer)

Seconds

Stopwatch

Weekday

Dive Time

Surface Time Temperature Dive Number (Free)

P02% (Nitrox) OLF% (Nitrox)

Total Ascent Time

Remaining Air Time

Surface Interval Time

Tissue Saturation Graph -Ascent Rate Bar Graph

1. Press [MODE] to wake up dive computer.



2. Wait for software to initialize.



3. When time and date appear, continue with adjusting settings.



GENERAL SETTINGS

1. Keep [DOWN] pressed.



2. Scroll with [DOWN] or [UP] and enter with [SELECT].



3. Change with [DOWN] or [UP] and confirm with [SELECT].




CHANGE MODES AND VIEWS

Press [MODE] to change main mode: time, dive, plan and memory.



Change botton row views in any mode with [DOWN] and [UP].



CHANGE DIVE MODE

The default dive mode is Air. If you want to use Nitrox, for example, change the mode under General Settings.

- 1. Keep [DOWN] pressed to enter General Settings. 2. Press [SELECT] to enter Dive Mode.
- 3. Change to Nitrox with [UP] and confirm with [SELECT].
- Press [MODE] to exit.

Before diving with Nitrox mode, set your 0,% and PO2 values.

- 1. Press [MODE] to enter dive mode
- Keep [DOWN] pressed to enter Nitrox Dive Settings.
- Press [SELECT] to enter Nitrox.
 - 4. Adjust 0,% with [UP] or [DOWN] and confirm with [SELECT].
 - 5. Adjust PO2 with [UP] or [DOWN] and confirm with [SELECT].
- 6. Press [MODE] to exit.

2. AUSTRALIA

SUUNTO CUSTOMER SUPPORT

+61 1800 240 498

1. www.suunto.com/support www.suunto.com/mysuunto

AUSTRIA +43 720 883 104 CANADA +1 800 267 7506 CHINA +86 010 84054725 +358 9 4245 0127 FINLAND FRANCE +33 4 81 68 09 26 GERMANY +49 89 3803 8778 ITALY +39 02 9475 1965 +81 3 4520 9417 IAPAN NETHERLANDS +31 1 0713 7269 **NEW ZEALAND** +64 9887 5223 RUSSIA +7 499 918 7148 SPAIN +34 91 11 43 175 SWEDEN +46 8 5250 0730 SWITZERLAND +41 44 580 9988 +44 20 3608 0534 +1 855 258 0900

SUUNTO

© Suunto Oy 11/2015. All rights reserved. Suunto is a registered trademark of Suunto Oy.



×|× ×|✓ PLAN

- 1. Press [MODE] until vou see PLAN NODEC.
- 2. Press [DOWN] or [UP] to scroll dive depths and check no-decompression times. The no-decompression time is shown in the center of the display.



- 3. Between consecutive dives, press [SELECT] to adjust surface time. 4. Press [MODE] to exit.
- The default dive mode is Air, so the dive planner shows calculations based on

If you are diving with Nitrox, change the dive mode to Nitrox and select your mix from the Nitrox dive settings before checking the diver planner.

◆ HISTORY


- 1. Press [MODE] until you see MEM. 2. Switch between History and Logbook with [DOWN] or [UP]. If you select history, you can choose between scuba and free dive history



3. Press [MODE] to exit.

□ DIVE

1. While in time or dive mode, keep [SELECT] pressed.





COMPASS COMPASS

2. Turn and rotate wrist to calibrate compass if needed.



3. Press [MODE] to exit compass



PAIR

- 1. Press [Mode] to change to dive mode.
- Keep [Down] pressed to enter settings.
- 3. Scroll to Tank Press Pairing with [Up] and press [Select].

SUUNTO WIRELESS TRANSMITTER (OPTIONAL)



4. Press [Up] to turn pairing on and and confirm with [Select].



- 5. Press [Mode] to exit settings. 6. Hold dive computer next to transmitter until code appears.



7. Transmission icon indicates active connection.



⚠ LOW BATTERY





SUUNTO WIRELESS TRANSMITTER (OPTIONAL)

HIGH PRESSURE



⚠ NO CONNECTION



1. Breath in gas and hold dive computer next to transmitter.





2. If still no connection, clear code under Tank Press Pairing setting and re-pair transmitter.



www.suunto.com/mvsuunto

















